




1. If the ESC firmware upgrade failed during the upgrading process, please restart the ESC again, and must upgrade the ESC firmware via the APP again (all the other functions are not available), the ESC will get right after the firmware upgraded successfully.
2. The Red Led will blink a faint light when the ESC in the firmware upgrade mode, and the Blue Led will blink a faint light when the ESC have data transmission.
3. Please do not turn off the ESC during the time of the ESC firmware upgrading process. (And the ESC only can be switched off after pressing the power button around 5 seconds)




- ❖ Do not let children use this product without the supervision of an adult.
- ❖ The ESC might get hot during use, be careful when handling it.
- ❖ When soldering input / output wires and connections, set the iron to 60W minimum.
- ❖ Always disconnect the battery after use, do not store with the battery connected.
- ❖ Do not use near flammable materials.
- ❖ If the ESC overheats, emits smokes or burns immediately discontinue use, disconnect the battery and seek assistance.

Specification				
Product Name	Mini-Z ESC	160A	150A	160A
Cont. Current	30A	160A	150A	220A
Burst Current	80A	760A	950A	1000A
Input Voltage	2-3S	2-3S	2-6S	2-4S
BEC Output	6.0V/2A	6.0V,7.4V/4A	6.0V,7.4V/6A	6.0V,7.4V/6A
Size(L*W*H)	23.5x13.7x9.8	37.0x38.2x31.5	55x48x37.5	55x40x36.5
Weight	9.5	96	165	155
ESC Programming Via	Mobile Phone APP	Mobile Phone APP	Mobile Phone APP	Mobile Phone APP
Firmware Upgrade	Supported	Supported	Supported	Supported
Waterproof	NO	NO	NO	NO
Car Applicable	1/28th	1/10th	1/8th	1/8th



Power On/Off ESC---1. Press the power button then the ESC will be powered on. 2. Press and holding the power button until the all LEDs died out, then the ESC will be powered off. (Note: Please place the throttle trigger on the neutral position: within 10%, otherwise the ESC can not be powered off.)

1. Connect the ESC with the battery and receiver well, then turn on the transmitter.
2. Press and holding the power button until the blue LED is on solid, the motor have a long beep at the same time, then release the power button, the red led will be on solid, the ESC enters to the calibration mode.
3. Pull the throttle trigger to the full throttle position, the blue led blinks three times and the motor beeps once, the full throttle position is saved.
4. Push the throttle trigger to the full brake position, the blue led blinks three times and the motor beeps twice, the full brake position is saved.
5. Release the throttle trigger to the neutral position, the blue led blinks three times and the motor beeps three times, the throttle calibration is completed.
6. The ESC can support reverse throttle calibration, if the transmitter throttle set reverse (it means pull the throttle will go to 1000 throttle position/normally is 2000, and push the throttle will go to 2000 throttle position/normally is 1000), then you do the throttle calibration the same way as usual (as above), it will not have any effects on the ESC for ward and revery way even if the transmitter throttle set

		
<p>Pull the throttle trigger to the full throttle position, Blue LED blinks three times, motor one beep</p>	<p>Push the throttle trigger to the full brake position, Blue LED blinks three times, motor two beeps</p>	<p>Release the throttle trigger to neutral position, Blue LED blinks three times, motor three beeps, throttle calibration done</p>
<p>Note: When you pull the throttle from neutral position to full throttle position, the Blue LED will blink, and the blink frequency will go faster when the throttles goes higher.</p>		

The ESC can support the 450Hz maximum PPM throttle signal.

The ESC throttle protection will be activated under the following situation, and the BLUE LED blinks double flash when the throttle trigger do not place on the neutral position when the ESC turns on.

If the ESC lost throttle signal during the operation, the BLUE LED will blink double flash, and the ESC will start to work again until the throttle signal is back to normal.

1. The sensorless mode is activated once the ESC detected the hall sensor signal at any time.
2. The ESC will work on sensorless mode once the ESC didn't detect the hall sensor signal at any time.
3. The ESC will have a slight power drop and restored soon during the moment of sensed and sensorless mode switching.
4. The PWM driving frequency will be selected automatically by the ESC on sensorless mode, and the manual setting is invalid.
5. It is invalid to set the brake PWM frequency less than 1KHz and forced recognized as 1KHz, if the ESC is on sensorless mode.
6. Boost and torque functions are out available on sensorless mode.

1. After the boost or turbo timing triggered, the RPM and current will be increased, and the battery/ESC/motor will be heating, so setting the proper timing and timing increased rate, and control the time of timing will effect the battery/ESC/motor service life.
2. The difference of the Boost and Turbo Timing:
 - The Boost timing will be triggered even though you do not pull the throttle trigger to the full throttle position.
 - The Turbo timing will be triggered only when you pull the throttle trigger to the full throttle position.
3. The Boost timing plus the Turbo timing is equal to the final opened timing when the throttle reaches its maximum position, and the final total timing is 60 degree (for Beast)

Pro 150A total timing is 15 degree). For example: If Boost timing set at 45 degree, and Turbo Timing set at 50 degree, so when the throttle reaches its maximum position, the Boost timing will be 45 degree, and Turbo Timing only can be opened at 15 degree.

4. If set the low voltage or over temperature protection, and the protection is activated, then all the timing will be closed.

1. Reset password: When the ESC turns on, press and hold the power button around 10 seconds, the ESC will restore the Bluetooth password to default settings.

Solutions

1. Check if all ESC & battery connectors have been well soldered or firmly connected.
2. Replace the broken switch.

1. Check all devices and try to find out all possible causes, and check the transmitter's battery voltage.
2. The RED LED blinks, single flash between every one second.
3. The RED LED blinks, double flash between every one second.

The car ran forward/backward slowly when the throttle trigger was at the neutral position.

1. The neutral position on the transmitter was not stable, so signals were not stable either.
2. The ESC calibration was not proper.

1. Replace your transmitter
2. Re-calibrate the throttle range or P-ne tune the neutral position on the transmitter.

Real-time Data	Item	Description
<p>The real - time data can be read only when the ESC have the throttle signal.</p> <p>The real - time data is 10% reference data with ± 1.0 accuracy, if you want to get the more accurate real - time data, you need to use the more professional equipment.</p> <p>The description of the real time data items:</p>	Input Throttle	The throttle from the Receiver to the ESC
	Output Throttle	The throttle from the ESC to the Motor
	Voltage	The battery voltage is being read by the ESC
	Min. Voltage	The minimum voltage was read by the ESC
	Temperature	The ESC temperature
	Max. Temperature	The maximum temperature was read by the ESC
	RPM	Revolutions per minutes
	Max. RPM	The maximum RPM was read by the ESC
	Adv. Timing	Advance Timing

